



ATS Panel

ATS PANEL

ATS panel is used to transfer the load where there is more than one power supply network to enable switching to the required power supply. Commonly, it transfers the mains power supply or generator supply to the system.

The panel performs switching operation via 2 contactors located in the panel, it does not decide either system is supplied from mains or generator. Generally it is triggered by control unit on generator or power analyser on mains supply. Mains supply / generator contactor becomes active when there is a 220 VAC signal on related connectors and the system is powered. There are warning lights on the front cover of panel to show the system is on power from which supply network.



Figure 1. ATS Panel External View



Figure 2. ATS Panel Internal View



Dudullu Organize Sanayi Bölgesi 2. Cadde No: 14
34775 Ümraniye İstanbul / Turkey
Tel : +90 216 561 47 74 (Pbx) • Fax : +90 216 561 47 50
www.etna.com.tr/en • info@etna.com.tr



ETNA®

0850 455 38 62
customer service